


Fog Light



Service Hints**F10 Front Fog Light Relay**

5-3 : Closed with the light control SW at HEAD position, dimmer SW at LOW position and fog light SW on

 : **Parts Location**

Code	See Page	Code	See Page	Code	See Page
C8	30	F10	30	J7	B 31
F3	28	F11	30		
F4	28	J6	A	31	

 : **Junction Block and Wire Harness Connector**

Code	See Page	Junction Block and Wire Harness (Connector Location)
1J	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
1M		
1O		

 : **Connector Joining Wire Harness and Wire Harness**

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA1	36	Engine Room Main Wire and Instrument Panel Wire (Behind the Reinforcement LH)

 : **Ground Points**

Code	See Page	Ground Points Location
EA	34	Front Right Fender Apron
EB	34	Front Left Fender Apron
IE	36	Left Kick Panel